

To configure CSRDS to capture Images and Campaigns from Quu:

1. In CSRDS select Properties from the Tools Menu.
2. Click the Other Tab

The screenshot shows the 'Other Additional Options' dialog box. A red box highlights the 'Web Service' section, which contains the following fields:

- Station ID: QUU Station ID
- User/SID: QUU SID
- Password: QUU Password

An arrow points from a label 'QUU Credentials' to the 'Web Service' section. Other sections in the dialog include:

- RDS Decoder Connection:** Maximum Speed (9600), Port (<None>), Data Bits (8), Parity (None), Stop Bits (1), Flow Control (Hardware selected).
- PAD Decoder Connection:** Maximum Speed (9600), Port (<None>), Data Bits (8), Parity (None), Stop Bits (1), Flow Control (Hardware selected).
- Misc:** Music Event Buffer (2 sec), Sat pad Buffer (sec), TZ Event Delay (HH:MM), IP Buffer Wait (300 ms), CSLogt Block (sec), Static Msg HeartBeat (MM:SS), Send Logo Every (000 sec).
- Artwork Directory:** Artwork (DSN1) ADHD1, Channel, Logo (DSN2) SLHD1, HD1, HD LotID From: 1000 to: 5000.

3. Enter your QUU Credentials
4. Click Continue to return to the Properties Window
5. Click OK to save the settings and return to the main Controller Window
6. Click F5-Start to put CSRDS back on-line